



# **AIRBUS A320 NORMAL CHECKLIST**

**BY:     ilacaptain.com**

### PRELIMINARY CHECKLIST

FUEL AND PAYLOAD	SET
GROUND CONNECTION	SET
ENGINE MASTER 1 & 2 SWITCHES	OFF
ENGINE MODE SELECTOR	CHECK NORM
WEATHER RADAR	SET OFF
L/G LEVER	DOWN
WIPER SELECTORS (both)	OFF
BAT 1 & BAT 2	AUTO
EXTERNAL POWER	ON
APU FIRE	IN and GUARDED
Agent Lights	OUT
APU Fire Test	PRESS
APU MASTER SW	ON
APU START	ON
APU BLEED	ON
ALL WHITE LIGHTS	OFF
X BLEED selector	AUTO
ZONE TEMPERATURE selectors	AS REQUIRED
COCKPIT LIGHTS	AS REQUIRED
RCL KEY	PRESS 3s
ENG, DOOR, HYD PAGE	CHECK
FLAPS	CHECK POSITION
SPEED BRAKE	CHECK RETRACTED AND DISARMED
PARKING BRAKE	ON
ACCU/BRAKES PRESS	CHECK
EMERGENCY EQUIPMENT	CHECK
RAIN REPELLENT	CHECK
REAR AND OVERHEAD CIRCUIT BREAKERS PANELS	CHECK IN
OVERHEAD CIRCUIT BREAKER PANEL	CHECK IN
GEAR PINS AND COVERS	CHECK ONBOARD/STOWED
EXTERIOR WALKAROUND	PERFORM

### PREPARATION CHECKLIST

RCDR GND CTL	ON
CVR TEST	PRESS AND MAINTAIN
CAPT & PURS/CAPT Switch	AS REQUIRED
CREW SUPPLY	AUTO
All ADIRS selector	NAV
STROBE LIGHT	AUTO
BEACON LIGHT	OFF
NAV LIGHT	ON
WING LIGHT	ON (AT NIGHT)
SIGNS Switch	ON/AUTO
EMER EXIT LT Selector	ARM
ANN LT	TEST
LDG ELEV Knob	AUTO
PACK FLOW selector	AS REQUIRED
ELEC pb (on the ECAM Control Panel)	PRESS
BAT 1 and BAT 2	OFF then ON
ENG 1 FIRE and ENG 2 FIRE	CHECK IN and GUARDED
AGENT 1 light and AGENT 2 light	CHECK OFF
ENG 1 TEST and ENG 2 TEST	PRESS and MAINTAIN
AUDIO SWITCHING SELECTOR	NORM
PA KNOB	RECEPT
MAINTENANCE PANEL	CHECK OFF
ISIS	CHECK
BRAKE PRESSURE	CHECK
CLOCK	CHECK and SET AS NECESSARY
A/SKID & N/W STRG	ON
RMP	ON AND TUNE
ACP INT knob	PRESS OUT / VOLUME CHECK
SWITCHING PANEL	CHECK NORM
ECAM STS	PRESS
ECAM PRESS	PRESS AND CHECK
THRUST LEVER	IDLE
GRAVITY GEAR EXTN	CHECK STOWED
ATC	AUTO
ALT RPTG	ON
ATC SYS 1	SELECT
DE-ICE & ANTI-ICE	AS REQUIRED
MCDU	SET (DIFS-RIP)
GLARE SHIELD	SET

### START AND PUSHBACK CHECKLIST

GROUND CONNECTION	ALL OFF
DOORS	CLOSED
BEACON LIGHTS	ON
APU BLEED AIR	ON
THRUST LEVERS	IDLE
ENGINE AREA	CLEAR
FUEL PUMP SWITCHES	ON
MODE SELECTOR	IGN / START
ENGINE MASTER 1	START
ENGINE 1 PARAMETER	MONITOR
ENGINE MASTER 2	START
ENGINE 2 PARAMETER	MONITOR
GENERATORS	CHECK
HYDRAULIC PUMP SWITCHES	ON
APU MASTER SWITCH	OFF
MODE SELECTOR	NORM
ECAM STATUS	CHECKED

### TAXI CHECKLIST

PROBE/WINDOW HEAT	AUTO
RUDDER TRIM	NEUTRAL
AUTOBRAKE	MAX
FLIGHT CONTROLS	FREE AND CORRECT
NOISE LIGHTS	TAXI
PARKING BRAKE	RELEASE
TAXI SPEED	Max. 20 knots
BRKS/GYRO/TURN COORDINATOR	CHECK
FLAP	T/O
SPEED BRAKE	ARM
RADAR & PWS	ON & AUTO
TRIM	SET
SEAT BELT	ON

**BEFORE TAKEOFF CHECKLIST**

ECAM MEMO	T.O NO BLUE
LANDING LIGHTS	ON
RUNWAY TURNOFF LIGHT	ON
NOISE LIGHT	T/O
PITOT HEAT	AUTO
DE-ICE	AS REQUIRED
PACKS	OFF
TCAS	TA/RA
TERRAIN ON ND	BOTH ON
CLOCK	RUN

**AFTER TAKEOFF CHECKLIST**

LANDING GEAR	UP
FLAPS	UP
SPEED BRAKE	DISARM
NOISE LIGHT	OFF
RUNWAY TURN OFF LIGHT	OFF

**DO NOT FORGET**

AT TRANSITION	SET STANDARD (CAPT + FO + ISIS)
AT 10,000 MSL	LANDING LIGHT RETRACT

**APPROACH CHECKLIST**

APPROACH BRIEFING	PERFORM
AT TRANSITION	SET QNH (CAPT + FO + ISIS)
AT 10,000 MSL	LANDING LIGHT ON
NAV AND RADIO	SET AND TUNE

**BEFORE LANDING CHECKLIST**

LS	ON
FLAP	LANDING POSITION
NOISE LIGHT	TAKEOFF
RUNWAY TURN OFF LIGHT	ON
SPEED BRAKE	ARM
LANDING GEAR	DOWN
AUTO BRAKE	SET
PACKS	OFF
GO-AROUND ALTITUDE	SET IN FCU
ECAM MEMO	NO BLUE

### AFTER LANDING CHECKLIST

SPEED BRAKE	DISARMED
NOISE LIGHT	TAXI
LANDING LIGHTS	OFF
RUNWAY TURN OFF LIGHT	OFF
RADAR & PWS	OFF
TERRAIN ON ND	BOTH OFF
FLAP	RETRACT
APU MASTER SW	ON
APU START	ON
BRAKE TEMP	CHECK
TCAS	OFF

### SHUTDOWN CHECKLIST

PARKING BRAKES	SET
THRUST LEVERS	IDLE
ENGINE MASTER 1 & 2	OFF
BEACON LIGHT	OFF
NOISE LIGHT	OFF
STROBE LIGHT	OFF
GROUND CONNECTION	ESTABLISH (CHOKE + GPU + ASU)
EXTERNAL POWER	ON
APU MASTER SWITCH	OFF
PASSENGER SIGNS	OFF
DOORS	OPEN
ANTI ICE	OFF
FLIGHT DIRECTOR	OFF
FUEL PUMPS	ALL OFF
ADIRS	OFF
RMP	OFF
EMERGENCY LIGHTS	OFF
NAV LIGHT	OFF
WING LIGHT	OFF
PANEL LIGHTS	OFF
BATTERIES	OFF
EXTERNAL POWER	OFF